



NORTH SHORE COMMERCIAL DOOR .COM

GARGE DOOR BOTOM REPLACEMENT KIT INSTALLATION GUIDE:

Tools Needed:

- DRILL
- 1/16"DRILL BIT
- SCREW DRIVER (PHILLIPS)
- VICE GRIPS
- HACK SAW (Not needed if the retainers do not need trimmed)

MATERIALS:

- RETAINERS
- RUBBER WEATHER SEAL
- SCREWS

Step One:

Disconnect your garage door opener trolley by using the pull handle. Open the door $\frac{3}{4}$ of the way and lock it in place by using the vice grips on the garage door rails. Remove old weather seal and track if applicable (**Do not remove your bottom brackets with the cable attached!!!!**)

Step Two:

Pre-Drill holes every 18 inches on the bottom of the Retainers. Next mount the bottom retainers. If you purchased and "L" Shaped retainer; the vertical portion is designed to be mounted on the inside of the garage and you can put a couple screws in that portion if you so desire. Make sure that each section of retainer is tightly fitted together and flush. This will allow the seal to slide in without getting snagged.

Step Three:

Slide the rubber seal in from the end of the track. You may need to feed it through the rails of the garage door to do this. As you slide the seal in, be sure that the seal is staying in the track. Trim the ends as needed after the seal retracts (it stretches slightly during installation)