



# NORTH SHORE COMMERCIAL DOOR .COM

## Entry Door Installation Instructions

### Materials supplied:

- (1) 3' or 4' aluminum retainer for the header depending on kit size
- (4) 3' 6" aluminum retainers for the sides, two needed per side
- Enough brush or bulb seal depending on the kit for the above retainers

Tools needed: Tape measure, Hacksaw, Phillips head screwdriver, Drill, Scissors or snips

### **Installing the header seal**

Measure the header of the entry door opening

Cut the 3 foot or 4 foot aluminum retainer to the width of the header

Slide the brush or bulb seal into the retainer trimming it to match the aluminum

With the door closed, hold the weather seal against the header

Sliding the assembly towards the door until the seal touches

Apply slight pressure against the door to insure a tight seal

Install the screws while holding the assembly in place

### **Installing the two side seals**

Next, measure for the sides

Measure from the threshold to the bottom of the newly installed header seal

Two 3' 6" pieces of aluminum retainer are needed per side

Cut one of the 3' 6" pieces of the aluminum retainer as needed to the height

Depending on the style kit:

Bulb seal kit: Slide one continuous piece of bulb seal into the two retainers trimming it to match the overall length of the aluminum retainers

Brush seal kit: Slide one 3' and one 4' piece of brush into the two retainers trimming it to match the overall length of the aluminum retainers

Slide the assembly toward the door until the seal touches

Apply slight pressure against the door to insure a tight seal

Install the screws while holding the assembly in place

Repeat the above steps for the other side seal