

SWEEP KIT INSTALLATION

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE BEGINNING

- Remove the brush or vinyl seal from the aluminum retainer. While it's closed, measure the width of the door. Measure and cut the aluminum to the desired size. If the existing end hole has been cut off, redrill a new hole.
 - **For brush kits:**
Cut the brush backing with hand snips to the length of the aluminum. Slide the brush into the retainer and crimp the aluminum ends with pliers in order to secure it.
 - **For vinyl kits:**
Cut the vinyl with knife or scissors $\frac{1}{2}$ inch shorter than the aluminum. Slide the vinyl into the retainer, leaving $\frac{1}{8}$ inch exposed on the end. Crimp the aluminum end with pliers in order to secure the vinyl. Pull the vinyl taut, exposing $\frac{1}{8}$ inch on the opposite end. Crimp it to secure.
 - Position the sweep on the closed door, allowing the brush or vinyl to seal against the threshold. Mark the holes and predrill the door with a $\frac{7}{64}$ -inch bit. Attach the seal with the fasteners provided.
-