



INSTRUCTION FOR RADIO CONTROL OPERATOR TRIPLE ENTRY TRANSMITTER MODEL C/GRC390-3K

Read the following instructions thoroughly before using the transmitter.

Match the transmitter to receiver

- Press and HOLD a button on transmitter for transmission.
- Then press the Smart/Learn button on your receiver. The adjacent indicator light will flash. Release the button of transmitter. The receiver will now operate when you press the button of transmitter.


Detail for add/remove a transmitter, please check with the instruction of your receiver.

To change frequency from 390MHz (default setting) to 315MHz, locate jumper, just above battery. Using needle nose pliers, completely remove jumper from position A --  (default setting) and move over to position B -- , and press jumper firmly into position.

WARNING!

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Regulation : This device complies with FCC Rules Part 15. Operation is subject to following two conditions: 1) This device may not cause harmful interference. 2) This device must accept an interference that may cause an undesired operation. Transmitter distance may vary due to circumstance beyond our control.



Jumper for frequency change
A-390MHz
B-315MHz



Slide the cover for battery replacement and frequency change

OMRC3903KC

