




WARNING LIGHT



Technical Specifications

- Working with auto flash (2Hz) or with externally driven flash (selectable with jumper)
- Power of the device by choosing the power supply terminal, it can be 24V AC, 24V DC, or 230V AC
- In-line fuse



- Jumper
 - C = Flashing externally managed
 - F = Flashing automatically managed
- STO1
 - Bracket for wall or pole mount
- FUSE
 - 1 A Fuse

Transmitter 
SOLUTIONS®

7380 S. Eastern Ave, Suite 124-320
Las Vegas, NV 89123
(866) 975-0101 • (866) 975-0404 fax
www.transmittersolutions.com