

# **RADIOEM144 - Rolling Code Transmitter**

## **Programming Instructions**

#### **Transmitter Programming Options**

The RADIOEM144 Rolling Code Transmitter can be used to control up to 144 doors with Open / Close / Stop function. Two rotary dials (Letters: A to L) and (Numbers: 1 to 12) permit for a proper door selection.

Transmitter	Functions
	<ul> <li>3-Button Transmitter.</li> <li>Operates up to 144 doors by using a combination of 2-rotary dials.</li> <li>Open / Close / Stop function.</li> <li>LED indicator.</li> <li>Soft-touch push-buttons, including a bright red stop button for easy identification.</li> <li>Includes 4 mounting screws and anchors.</li> <li>2 AA batteries.</li> <li>Wall or post mounting.</li> </ul>
3-Button Transmitter (up to 144 doors)	
RADIOEM144	

### **Transmitter to Operator Programming**

The On-Board Radio Receiver, featuring Rolling Code Technology, is factory installed on all operators equipped with an Electronic Control Board **BOARD 070** / **RADIOKIT005**. **RADIOEM144** is also compatible with **RADIORE102**.

**Note:** You can match 144-Door, 3-Button AND 1-Button Transmitters with the same Receiver. Mix and match any Transmitters from the 100 Series accordingly for your application (ordered separately). One Receiver will accept up to 50 Transmitters.

## Match RADIOEM144 Transmitter to the On Board Radio Receiver (RADIORE100)

#### To MATCH the Transmitter to the Receiver:

- 1. Adjust the Transmitter's rotary dials to the desired positions to permit for the proper door selection.
- 2.HOLD the Receiver's **LEARN** button until the LED flashes for approx. 2 sec. (frequency of 1 sec. ON / 1 sec. OFF).
- 3.On the Transmitter, HOLD any button until the Receiver's LED stops flashing.

#### To DELETE ALL Transmitters from the Receiver's memory:

1. HOLD the Receiver's **LEARN** button until the LED flashes for approx. 10 sec. (frequency of 1/3 sec. ON / 1/3 sec. OFF).




Figure 1 - RADIORE100 (ECB BOARD070 / RADIOKIT005)

For further information, please consult the operator's Installation & Instruction Manual or contact our Technical Support Department at **1-800-361-2260**.