

WALLMOUNT TRANSMITTER

Model WB-201

1. INTRODUCTION

In this package, you will find a Wallmount Transmitter with 12V alkaline battery, double-sided foam tape, wall anchors and screws.

4 pcs
wall anchors

4 pcs 3x18 screws
(Included)


Double-sided
foam tape



2. PROGRAMMING TRANSMITTER TO THE SWING DOOR OPENER

Follow the instructions below to program the transmitter to the Swing Door Opener model DM-001:

1. The door opener should be in standby mode, i.e. adapter plugged in but the swing door opener should not be operating, only the red LED should be on steadily.
2. Press and hold the "Learn" button, the red LED will start to flash and buzzer will beep indicating the door opener is in learn mode.
3. Press and hold the button on the transmitter you would like to program while you are holding onto the learn button on the door opener, you should hear a long beep and the red LED will be off.
4. You may now release the button on the transmitter and the learn button on the door opener and the red LED will be on steadily. You have now successfully programmed the transmitter to the door opener.




3. OPERATION

To select the timer mode in the Swing Door Opener, user can activate the door opener to open the door and the door will be closed automatically after it has been opened for a specified period of time. So the user does not need to close the door, or the door will not be left open even if the user forgets to close it.

When the door is closed, pressing the button on the wall mount transmitter will open the door. After the preset time period, the door will be closed automatically.

When the door is operating, the orange LED will flash and the buzzer will beep.

Please refer to the user's instruction of Swing Door Opener for details regarding the Timer mode and Timer setting.




4. INSTALLATION

We have included screws, wall anchors and a template to aid in the installation of this wall mount transmitter.

To mount the transmitter:

1. Position the wall mount transmitter on the wall or surface by using either the double-sided tape or screws.
2. If you are using screws, tape the template to the wall or surface where you would like the wall mount transmitter to be.
3. Unscrew the 4 screws on the transmitter case to pry off the cover.
4. Screw the wall mount transmitter in place where you started the screws.
5. Install the cover to the case and apply the 4 screws firmly on the case.



5. TROUBLE SHOOTING

Q: The door opener does not respond after pressing the button on the transmitter.

- A:
- Ensure that the button is pressed and held for one second on the transmitter.
 - Check that the battery is inserted properly.
 - Ensure the door opener is powered up.
 - Program the transmitter again. Refer to "Programming Transmitter to the Swing Door Opener" section.

6. ERASE PROGRAMMED TRANSMITTER(S)

Programmed transmitters can be erased by following the instructions below:


1. Unplug the door opener when it is in standby mode.
2. Press and hold the learn button, then plug the adapter back in while holding the learn button.
3. You should see the red LED flashing and buzzer beeping rapidly. This indicates all the transmitters have been erased and you may release the learn button. You may now release the learn button.

Note: When performing the erase operation, all the programmed transmitters will be erased. This operation cannot erase an individual transmitter.

7. BATTERY

To replace the battery:

1. Unscrew the 4 screws on the case to remove the cover.
2. Slide the transmitter off from the bracket.
3. Pry off the battery door from the transmitter.
4. Pry out the old battery from one end.
5. Place the new battery in position. A diagram under the battery indicates which end is positive and which is negative.
6. Close the battery cover.
7. Slide the transmitter back into the bracket.
8. Install the cover to the case and apply the 4 screws firmly on the case.



8. FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

9. WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

10. CUSTOMER SERVICE

If you would like to order Skylink's products or have difficulty getting them to work, please :

1. visit our FAQ section at www.skylinkhome.com, or
 2. email us at support@skylinkhome.com, or
 3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST.
- Fax (800) 286-1320

CUSTOMER SERVICE

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3
Email: support@skylinkhome.com
<http://www.skylinkhome.com>
P/N. 1012XXX
US Patent D380895, 6243000B1
©2006 SKYLINK GROUP