


INSTRUCTIONS FOR ONE BUTTON, ONE FREQUENCY

Garage Door & Gate Openers

Read the following instructions thoroughly before using the remote.

Programming Remote Controller to the Opener

- Garage door opener must have a working light bulb as it will flash indicating successful programming.
- Locate learn button on front or rear of garage door/gate opener.
- Press and HOLD desired button on hand held remote.
- Then press and release the smart/learn button on opener. The LED light will turn on. The opener light bulb will flash when programming is completed.
- After light bulb has stopped flashing then test remote control.
- Repeat steps above to program additional openers/devices by selecting a different button on remote control. This remote can control up to three openers/devices, one per button.



Slide the cover for
battery replacement
Battery Type: 23A

Trouble Shooting

- In the event that the remote control fails to operate correctly, check and replace battery if necessary.
- If programming is unsuccessful, check to make sure jumper is in correct position for your model opener. You may need to change frequency setting. See illustration for jumper location.
- Verify light bulb in garage door opener is working.
- Check that there are no obstructions to garage door opening and safety beam.

Warning

To avoid possible serious injury or death from a garage door or moving gate:

- Keep all remote controls out of children's reach at all times. Never allow children near batteries!
- Only activate door or gate when it is in clear view and is in proper working condition.
- Always completely monitor garage door and gate opener until completely opened or closed.
- Never allow anyone to cross area of opening and closing of moving garage door or gate.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Regulations: This device complies with FCC Rules Part 15. Operation is subject to following two conditions:

- 1) This device may not cause harmful interference. 2) This device must accept an interference that may cause an undesired operation. Transmitter distance may vary due to circumstance beyond our control.

Copyright ©2011 by Heddolf/Keystone Remotes

ME-59-0002

